

**PART 2. EN-ROUTE (ENR)****ENR 2. AIR TRAFFIC SERVICES AIRSPACE****ENR 2.1 FIR, UIR, TMA****1.1. FLIGHT INFORMATION REGION (FIR)**

Juba FIR is being managed by Khartoum FIR with future transfer to South Sudan in process. South Sudan is providing services to the following airspace at FL245 and below.

Name Lateral limits Vertical limits Class of airspace	Unit Providing Service	Call Sign Languages Area and Conditions of Use Hours of Service	Frequency/ Purpose	Remarks
1	2	3	4	5
<p>JUBA FIR</p> <p>10°08'42.48"N, 023°29'30.80"E; 09°51'49.24"N, 030°51'55.33"E; Thence clockwise via the 50 NM arc of a point located at 09°33'47.40"N, 031°39'11.41"E (MALAKAL VOR) to; 10°22'47.00"N, 031°50'21.90"E; Thence Northeasterly via the South Sudan – Sudan border to; 10°46'34.00"N, 032°11'01.00"E; 10°32'53.94"N, 034°32'06.78"E; 08°00'00.00"N, 033°00'00.00"E; 04°00'00.00"N, 036°00'00.00"E; 04°00'00.00"N, 030°12'16.00"E; Thence clockwise along the South Sudan border with CONGO (DRC) and CENTRAL AFRICAN REPUBLIC and CHAD to; 10°08'42.48"N, 023°29'30.80"E.</p> <p>Upper Limit: FL245</p> <p>-----</p> <p>Lower Limit: SFC</p> <p>CLASS G</p> <p>Unless otherwise designated.</p>	Juba Approach Control	<p>JUBA APPROACH</p> <p>English</p> <p>Juba (FIR) Airspace</p> <p>H24</p>	123.9	<p>Current radio frequency in use is via Juba Approach and range may be limited.</p> <p>If Juba Approach on 123.9 not reachable attempt Juba Tower on 118.4.</p> <p>Hours of operation may be limited.</p> <p>New radios and additional frequencies are under development.</p>

**1.2. UPPER INFORMATION REGION (UIR)**

Not Applicable. UIR airspace above FL245 is being managed by Khartoum FIR with future transfer to South Sudan in process. See Republic of Sudan AIP for UIR information.

## 1.3. TERMINAL CONTROL AREA (TMA)

Name Lateral limits Vertical limits Class of airspace	Unit Providing Service	Call Sign Languages Area and Conditions of Use Hours of Service	Frequency/ Purpose	Remarks
1	2	3	4	5
<p>JUBA TMA T1</p> <p>04°00'00.00"N, 033°01'18.00"E; 04°00'00.00"N, 030°12'16.00"E; Thence Northwesterly along the South Sudan border with CONGO (DRC) to 04°7'05.00"N, 030°06'42.00"E; Thence clockwise via the 100 NM arc of a point located at 04°52'33.54"N, 031°35'59.11"E (JUBA VOR) to; 04°00'00.00"N, 033°01'18.00"E;</p> <p>Upper limit: FL245 ----- Lower Limit: FL140 ----- CLASS E</p>	Juba Approach Control	<p>JUBA APPROACH</p> <p>English</p> <p>Juba TMA</p> <p>H24</p>	123.9	<p>If Juba Approach on 123.9 not reachable attempt Juba Tower on 118.4.</p> <p>Hours of operation may be limited.</p> <p>New radios and additional frequencies are under development.</p>
<p>JUBA TMA T2</p> <p>A circle with a radius of 50 NM centered on a point located at 04°52'33.54"N, 031°35'59.11"E (JUBA VOR)</p> <p>Upper limit: FL140 ----- Lower Limit: FL60 ----- CLASS E</p>				

---

**ENR 2.2 OTHER REGULATED AIRSPACE**

-NIL